



Use and Care Guide

White River Bath, LLC shower enclosures are made with tempered safety glass, the finest aluminum, and high quality hardware. With proper care and maintenance, your White River Bath enclosure will provide many years of use. White River Bath discourages using harsh and abrasive cleaners on any part of your shower as doing so may damage the metal or glass on your enclosure. We recommend:

- Use a shower squeegee to clean glass doors after each use.
- To avoid soap deposits or lime buildup in hard water areas, wipe the door dry after each use.
- Wipe the doors with a mild detergent diluted in water to keep the door looking new.
- Never use hard bristle brushes, abrasive sponges or sharp instruments on the glass panels or framing. They can scratch some glass and metal surfaces.
- Never use cleaners containing abrasives, ammonia, bleach, acids, waxes, alcohol or solvents as they may damage the finish. Do not let cleaners soak on surfaces for an extended period as doing so may discolor or mar the finish.
- Rinse and wipe fixtures after cleaning to prevent soap buildup and water spots.
- Keep shower doors open so that air can circulate and dry out the enclosure

Approved Products:

- Windex (Standard, Vinegar, Alcohol, Ammonia)
- SprayWay Spray Cleaner (or other alcohol-based foaming cleaners)
- Scrubbing Bubbles (or other automatic leave-to-dry daily shower cleaners)
- 7th Generation, Method (or other mild Green cleaners)

Avoid Product Properties: (warranty may be voided)

- Avoid the use of any harsh or chemical cleaners
- Avoid the use of any abrasives or polishes including Water Spot Removers, Toothpaste, Wax or Oil or Petroleum Based Cleaners, Rough Cleaners with Gritty Additives
- Avoid the use of Acids or Alkalis that you would not want in contact with your skin for an extended period of time